

Important Warnings:

DO NOT USE FUEL BURNING DEVICES IN THIS TENT AT ANY TIME. This includes but is not limited to lanterns, heaters, stoves, candles, hibachis and similar devices. These devices consume oxygen and release carbon monoxide which could lead to serious injury and/or death when used in a tent.

KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. The fabric in this tent is flame resistant and conforms to CPAI-84 specifications. **It is NOT FIRE PROOF.** This tent will burn when it is subjected to continuous contact with a flame source. Avoid application of any foreign substance or chemical preparation to the tent fabric. Such applications may reduce or eliminate the fire resistant properties of this tent fabric.

This tent is designed to be used inside a trampoline safety enclosure. Do not attempt to use other than as directed. Installation of this tent should be done under adult supervision. Do not attempt to install the tent by climbing up the safety enclosure to connect the cords. Do not use the Trampoline as a jumping apparatus while the tent is installed. Do not bring sharp objects into this tent.

This tent is designed to provide the user with a water resistant cover while using the trampoline bed as a sleeping and play surface during mild weather conditions. Do not use this tent as protection against extreme weather conditions. Seek permanent shelter during electrical storms, high winds and hail. Tent should be restricted to happy kids.

Remember to have lots of FUN in your new AlleyOop Sports™ Tent!

Look for these other accessories for your AlleyOop Sports™ Product:



Catch Air like the Pros!

Basketball Set



Game Pack



PO Box 2446, Saratoga, CA 95070

1-866-ALLEYOOP (255-3966)
www.alleyoopsports.com

TN-INS-A-0299 r0

For Use Inside the



Fun & Fitness Center

Installation Instructions



PO Box 2446, Saratoga, CA 95070

1-866-ALLEYOOP (255-3966)
www.alleyoop sports.com

TN-INS-A-0299 r0

Dear AlleyOop Sports™ Customer:

Thank you for purchasing this tent. We hope you and your family have many great hours together enjoying this product.

We want you to know we are dedicated to bringing safe and fun family oriented products into the backyard.

Thanks again,



Step 1 - Inspect the contents of this package. The package includes one tent, one tent sack, one 8 ft. elastic cord, eight 3 ft. elastic cords, eight 5 in. elastic cords and this instruction sheet.



Step 4 - Locate a sewn-in loop mid-way down the side of the tent. Thread a loop on one end of a 3 ft. elastic cord through the tent loop. Thread the other end of the cord through the protruding cord loop to form a tight slip knot.



Step 5 - Hook the loop on the end of the 3 ft. cord over the top ball cap on the adjacent pole. Repeat steps 4 and 5 on each of the remaining 7 sewn-in loops mid-way around the tent. *If necessary, maintain tension by wrapping the cord under the eye hook and around the pole before looping over the ball cap.*



Step 2 - Locate the sewn-in loop at the top of the tent. Uncoil the 8 ft. elastic cord and thread one of the looped ends through the loop at the top of the tent.



Step 3 - Spread the tent out on the trampoline bed. Orient the tent door so it is near the safety enclosure entrance. Hook the end loops over the top ball caps on two opposite poles.



Step 6 - Locate a sewn-in loop along the bottom of the tent. Thread a loop on one of the 5 in. elastic cords through the tent loop. Thread the plastic hook end of the cord through the protruding cord loop to form a tight slip knot.



Step 7 - Connect the plastic hooked end of the cord to the metal "D" ring on the trampoline mat closest to the matching safety enclosure pole. Repeat steps 6 and 7 on each of the remaining 7 sewn-in bottom loops. **Congratulations. . . You're Done!**