

Adapter works on AlleyOOP and JumpSport trampolines with Octagon kit installed.

Basketball backboard and trampoline sold separately.

Basketball Adapter Kit User's Manual

WARNING

Read these materials prior to assembling and using this basketball set



DO NOT attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis or death, even when landing in the middle of the bed.



DO NOT allow more than one person on the trampoline. DO NOT allow more than one person inside the trampoline enclosure. Use by more than one person at the same time can result in serious injury.

Use trampoline only with mature, knowledgeable supervision.



DO NOT attempt to jump over the barrier.



DO NOT intentionally rebound off the barrier.
DO NOT hang from, kick, cut or climb on the barrier.

CALIFORNIA PROP. 65 WARNING
This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Retain address information for future use.

JumpSport, Inc.
1680 Dell Ave.
Campbell, CA 95008 U.S.A.

1-408-213-2551
www.JumpSport.com

Patent info at: patents.JumpSport.com

Instruction Manual P/N: INS-P-21233-01D
Copyright © 2017, by JumpSport, Inc. All rights reserved.

Assembly and Installation Instructions

Thank you for purchasing a AlleyOOP Basketball Adapter Kit!

The following pages contain diagrams, pictures, and written instructions for installing your basketball adapter kit.

Familiarize yourself with the Assembly and Installation Instructions before beginning installation.

For installation questions, please contact JumpSport's Customer Service department at:

408-213-2551

6:00am – 5:00pm Monday through Friday, Pacific Time


Tools

Installation of the basketball adapter kit requires a 13mm hex wrench and a 5mm Allen wrench, both of which are included in the box (see Reference #3 and #4). An 8 foot A-Frame ladder will be useful for some steps (use care and follow procedures for use). Safety glasses and gloves are also recommended for safety.



Parts List

Your basketball set adapter kit is shipped with the parts shown below. If any parts are missing, immediately call JumpSport Customer Service at 408-213-2551.

Reference #	Part #	Description	Quantity
1a	CON-P-21064-01	Backboard Cross Connector (adapter pole)	1
1b	PLU-P-10112	38mm round plug	1
2a	BOL-P-11630	M8 bolt, Allen head	1
2b	WAS-P-10082	Washer	2
2c	NUT-P-10084	M8 Nylock nut	1
2d	NUT-P-10622	M8 acorn nut, capped end, black	1
3	TOO-P-10158	Wrench, 13mm hex	1
4	TOO-P-10159	Wrench, 5mm Allen	1




Assembly and Installation Instructions



1) Assemble basketball set as explained in your basketball set instruction manual, using the Type A assembly instructions. When you get to Step 10 in that manual, instead of installing the basketball set to the top of a safety enclosure pole, install it to the adapter pole included with this kit (Fig. 1).

2) Remove pole cap and corner connector from top of pole where you want basketball set to be installed (*should be on a pole opposite the entrance to the safety enclosure*) by disconnecting adjacent Octagon rods. Connect adapter pole with basketball set installed, to top of pole that you prepared in previous step. Reconnect the Octagon rods to the new connector.



3) Using M8 Allen bolt, M8 Nylock nut, and M8 acorn nut (included with this kit), secure adapter pole with basketball set to top of safety enclosure pole. Tighten Nylock nut securely, but only hand-tighten acorn nut.

IMPORTANT: Bolt must be installed so threaded end points away from trampoline. The acorn should be on outside of pole.

Basketball set and adapter pole should now be secured to top of safety enclosure pole.

Your basketball adapter kit is now installed!

To remove the basketball adapter kit, follow the Installation Instructions in reverse order.

Please remember, do *not* hang from the basketball set.

JumpSport®

Limited 90 Day Warranty

What is covered by this warranty? This warranty covers any defects in materials or workmanship on all of the components of the JumpSport Basketball Adapter Kit, and is extended exclusively to the original retail purchaser.

How long does this coverage last? Warranty coverage for each component begins from the original date of purchase and lasts for 90 days.

What will JumpSport do? If you return the defective part to JumpSport, as instructed below, JumpSport will either repair or replace such part, at JumpSport's discretion, and return it to you.

What is not covered by this warranty? This warranty does not cover expenses of on-site labor, shipping costs, travel, assembly or disassembly, or other charges associated with the repair or replacement of covered components. This warranty also does not cover any problem that is caused by abuse, misuse, commercial or public use, ordinary wear and tear, weathering, acts of God (such as wind and lightning), failure to follow directions, improper installation, improper maintenance, or any silk screened graphics. Rust is a natural occurrence with any outdoor steel product and is likewise not covered by this warranty, to the extent that it does not affect the structural integrity of the part. (This warranty does not cover the trampoline or any related safety enclosure to which the basketball set attaches. See individual trampoline and safety enclosure warranties for specific coverage details for those products.)

JUMPSPORT IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY LOSS, INCLUDING BUT NOT LIMITED TO ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

How to get a defective part replaced:

- 1) Call the JumpSport Customer Service department at 408-213-2551 to obtain a Return Authorization number. All returns must be pre-authorized.
- 2) Send the part(s) to the designated Service Center, along with a copy of your original sales receipt and a brief written description of the problem, including how it occurred. You must pay freight and insurance to return the part to JumpSport. At JumpSport's sole discretion, we may ask you to send photographs in addition to or in lieu of returning the part.
- 3) After inspecting the returned part(s), JumpSport will make a final determination whether the part is covered by this warranty. We reserve the right to examine photographs or physical evidence concerning parts claimed to be defective prior to making a final determination concerning the claim. A repaired or replacement part will be returned to you. (Shipping charges may apply.) Please allow 3 to 4 weeks for delivery.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.