

Important Warnings:

DO NOT USE FUEL BURNING DEVICES IN THIS TENT AT ANY TIME. This includes but is not limited to lanterns, heaters, stoves, candles, hibachis and similar devices. These devices consume oxygen and release carbon monoxide which could lead to serious injury and/or death when used in a tent.

KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. The fabric in this tent is flame resistant and conforms to CPAI-84 specifications. **It is NOT FIRE PROOF.** This tent will burn when it is subjected to continuous contact with a flame source. Avoid application of any foreign substance or chemical preparation to the tent fabric. Such applications may reduce or eliminate the fire resistant properties of this tent fabric.

This tent is designed to be used inside a trampoline safety enclosure. Do not attempt to use other than as directed. Installation of this tent should be done under adult supervision. Do not attempt to install the tent by climbing up the safety enclosure to connect the cords. Do not use the Trampoline as a jumping apparatus while the tent is installed. Do not bring sharp objects into this tent.

This tent is designed to provide the user with a water resistant cover while using the trampoline bed as a sleeping and play surface during mild weather conditions. Do not use this tent as protection against extreme weather conditions. Seek permanent shelter during electrical storms, high winds and hail. Tent should be restricted to happy kids.

For Use Inside the

JumpSport®

Safety Enclosure

Installation Instructions

Remember to have lots of FUN in your new JumpSport™ Tent!

Look for these other accessories for your JumpSport™ Product:



Catch Air like the Pros!

Basketball Set



Game Pack



JumpSport®

2055 South 7th Street, Suite A, San Jose, CA 95112

1-408-213-2551

www.jumpsport.com

TN-INS-J-0093r1

JumpSport®

2055 South 7th Street, Suite A, San Jose, CA 95112

1-408-213-2551

www.jumpsport.com

TN-INS-J-0093r1

Dear JumpSport™ Customer:

Thank you for purchasing this tent. We hope you and your family have many great hours together enjoying this product.

We want you to know we are dedicated to bringing safe and fun family oriented products into the backyard.

Thanks again,

JumpSport®



Step 2 - Locate the sewn-in nylon loop at the top of the tent. Uncoil the 8 ft. elastic cord and thread one of the elastic looped ends through the nylon loop at the top of the tent.



Step 1 - Inspect the contents of this package. The package includes one tent, one tent sack, one 8 ft. elastic cord, eight 3 ft. elastic cords (pre-installed), eight 5 in. elastic cords (pre-installed) and this instruction sheet.

**Enclosure shown in some photos may be different, but tent installation is the same.*




Step 3 - Spread tent out on the trampoline bed. Orient the tent door so it is near the safety enclosure entrance. Lift the top net strap off the ball cap on furthest pole to right (as shown) and install the elastic tent loop around cap. Repeat step on opposite pole.

TN-INS-J-0093r1



Step 4 - Start at the entrance with one of the 8 pre-installed, upper cords. Install the loop over the top ball cap on the adjacent pole. Repeat step 4 for each of the remaining 7 upper cords around the tent. *If necessary, maintain tension by wrapping the cord around the pole before looping over the ball cap.*



Step 5 - Start at the entrance with one of the 8 pre-installed, lower cords. To install the lower cord, pull it underneath the frame pad and rail to the adjacent leg. Wrap cord around the leg and pole and connect hook back to cord. Repeat step 5 for each of the remaining 7 lower cords around the tent.



AlleyOOp Tent shown.

Installation is now complete. Enjoy the fun!

TN-INS-J-0093r1