


Thank you for purchasing the **AlleyOop Sports® Rebounder** Trampoline with **Staged-Bounce™** and **Infinite™** Technology.

With the Staged-Bounce™ Rebounder, the springs engage in "stages" instead of all at once, making for a softer initial impact. The Infinite™ functionality allows users to customize the bounce by tightening or loosening the spring connections.

### HOW TO ADJUST THE MODEL 730si:

The spring-tension can be loosened or tightened by turning the head of the spring-connectors up to two complete turns (the allen wrench - supplied in the pocket under the spring pad - will be necessary to perform this step). Pull the top of the pad towards the outside of the frame and wrap it underneath the frame to expose the outer edge with the adjustable spring-connectors. The head of each spring-connector can then be adjusted (see picture below).

**IMPORTANT:** Replace the pad after tightening or loosening spring connectors before use.



### STORAGE:

For compact storage, simply pull each leg of the trampoline downward, and fold toward the center of the trampoline.



Model 530i with Staged-Bounce Technology  
Model 730si with Staged-Bounce and Infinite Technology



For questions about this product, call 1-408-213-2551

[www.jumpsport.com](http://www.jumpsport.com)

### Warnings:

- **This trampoline is designed for indoor, residential use only.**
- **Use only in an area with no obstructions around the trampoline, and with ample head room.**
- **Perform a check with each use to make sure the legs are securely fastened, the pad is in place, and springs are securely connected**
- **Step on and off of the trampoline - do not jump on or off.**
- **Trampoline is designed for one jumper at a time.**
- **Do not use as a rebounding surface to any other object.**
- **Practice controlled jumping - take a break from exercising if you are tired.**
- **Make all users aware of these warnings.**