



# Installation Instructions for Exercise Handle Bar

JumpSport Customer Service phone #: 408-213-2551



**1)** Familiarize yourself with the leg pieces (leg and leg cap), leg hardware (leg bushing, lock washer, Allen bolt, and leg plug), and the Allen wrench/drill bit.

**IMPORTANT:** Be sure leg caps are installed securely over bottom of legs, as shown above.



**2)** The 2 handle legs will be installed in place of the normal legs at the 2 locations shown above. Turn trampoline upside-down and fit leg sockets over stud on trampoline frame. Notch in leg socket lines up with pin on stud. All leg hardware fits inside of leg socket, in the order shown in Step 1. Securely tighten Allen bolts with supplied 6mm Allen wrench. Be sure the Fitness Trampoline logo is centered between the 2 handle legs. When all legs are installed, turn your rebounder over.

# CAUTION


## Avoid Injury.

Exercise handle bar (when attached to the rebounder) is not designed to support your entire weight. It is to aid with balance and provide exercise versatility.

- 2) Connect side handles to top handle, and secure with small thumb screws to create a "top assembly".
- 3) Lower top assembly into handle legs. *You may have to rotate entire top assembly 180 degrees for holes to line up.* Adjust height as necessary, before securing with large thumb screws.

## Your exercise handle bar is now installed!

To remove the handle, follow the installation instructions in reverse order.



## Limited Warranty

This warranty covers any defects in materials or workmanship for one (1) year from the original date of purchase. This warranty is limited exclusively to original retail purchaser, and does not cover public or commercial use. For additional warranty details, please visit <http://www.jumpsport.com/assembly.htm> and select the current JumpSport® Fitness Trampoline™ User's Manual.

(Pictures are for illustration purposes only and may not match actual product.)