


OPEN

START HERE

RETAIN THIS CARD FOR REFERENCE

⚠ WARNINGOnly **OPEN/UNFOLD** this way or serious injury may occur.**SEE
OTHER
SIDE****1**

Disconnect the loop portion of half of the bungees (every other one)

**2**

Make sure wire locks on hinges are in the fully open position.

3

Install one leg to use as handle. Grasp firmly.

4

Stand on frame and mat, push leg away.

5

Frame Snaps Open

6




Lift the trampoline frame near the hinge (DON'T Grasp Hinge or injury may occur) and fully close the hinge locks on each side.

7

Remove leg, flip frame so top is facing up. Reinstall bungees, and adjust cord spacing. Install legs.

FULLY OPEN

Hinge Wire Lock

**FULLY CLOSED**

Unsafe Wire Lock Position

6

Tension is Relieved

5

Pull Leg Towards You

4

Stand on the frame and the mat

3

Lift the trampoline frame near the hinge (DON'T Grasp Hinge or injury may occur) and fully open the hinge locks on each side.

2

Flip trampoline upside down. Remove all but 1 leg

1

Disconnect the loop portion of half of the bungees (every other one)

⚠ WARNINGOnly **CLOSE/FOLD** this way or serious injury may occur.**CLOSE**
START HERE



WARNING

SEE OTHER SIDE ► for proper folding instruction or serious injury may occur.




WARNING



Make sure Hinge Wire Locks are in the closed position at all times while in use.

Frame can snap shut when resting on its side, if hinges are not locked and trampoline is in an unsafe position


Hinges must be in a vertical position when using or handling the trampoline on its side.



**Unsafe Wire
Lock Position**



**Unsafe Hinge Position
May Snap Shut When Handled**



**Hinges
in Safe,
Vertical
position**

Safe Hinge Position

www.JumpSport.com 1-888-567-5867

Please find more tips in the owners manual, or contact our customer service department with any questions you may have.