

Avoid Injury.

Exercise handle bar (when attached to the rebounder) is not designed to support your entire weight. It is to aid with balance and provide exercise versatility.

1) Familiarize yourself with the Handle Bases [LEG-A-21797-00 / LEG-A-21801-00], and that the two parts could be described as being "mirror images" of each other.




2) Assemble the Handle Top to Handle Sides according to the leg type of your Fitness Trampoline to make a Handle Top Assembly:

- If you have a frame with straight legs, snap the Handle Sides [HAN-A-21051-00] into the holes that are closest to the inside of the U of the Handle Top [HAN-A-21658-00].
- If you have a frame with arched legs, snap the Handle Sides [HAN-A-21051-00] into the holes that are on the backside of the U of the Handle Top [HAN-A-21658-00].

3) Slide one Handle Base onto the Handle Top Assembly. Align one of the holes on the Handle Side with the hole at the top of the Handle Base. **Note: The Clamp Nuts for tightening the Clamps should be on the inside of the handle assembly when the holes are aligned. If not, swap Handle Bases.** Insert a Large Thumb Screw [SCR-P-11707A] and tighten until the Handle Top Assembly and the Handle Base are firmly connected.

Repeat with the other Handle Base, making sure to select the same hole height for both sides.



Note: assembly shown above is for frame with arched legs. Orientation is slightly different than shown for straight leg assembly, but Clamp Nuts for tightening the clamp should still be on inside of U assembly

4) Place the Handle Assembly adjacent to two legs on the Fitness Trampoline. Ideally, the logo will be in the middle. **Note:** The Large Thumb Screws for adjusting the handle height will be facing out, away from the frame when oriented correctly, and the Handle Bases should be on the ground.

Also Note: If you have a folding trampoline, ensure one of the hinges is between the two Handle Bases as shown.

Clamp the Handle Assembly securely to the legs on the trampoline frame by tightening the Clamp Nuts until snug.

Your exercise handlebar is now installed!

With the Handle Assembly firmly fixed to the trampoline, you can adjust the height of the handle by selecting the appropriate hole on the Handle Sides, and re-connecting firmly, using the Large Thumb Screws.

Now that the handle is customized to the height you desire, the Handle Assembly can be removed and re-connected to the frame quickly, using the Clamp Nuts.



JumpSport®

Limited Warranty

What is covered by this warranty? This warranty covers any defects in materials or workmanship on all of the components of the JumpSport Exercise Handlebar, and is extended exclusively to the original retail purchaser.

How long does this coverage last? Warranty coverage for each component begins from the original date of purchase and lasts for 1 year (for private home use) or 90 days (for commercial or public use).

What will JumpSport do? If you return the defective part to JumpSport, as instructed below, JumpSport will either repair or replace such part, at JumpSport's discretion, and return it to you.

What is not covered by this warranty? This warranty does not cover expenses of on-site labor, shipping costs, travel, assembly or disassembly, or other charges associated with the repair or replacement of covered components. This warranty also does not cover any problem that is caused by abuse, misuse, ordinary wear and tear, outdoor use, weathering, acts of God (such as wind and lightning), failure to follow directions, improper installation, improper maintenance, or any surface coatings. Rust is a natural occurrence with any steel product and is likewise not covered by this warranty, to the extent that it does not affect the structural integrity of the part.

JUMPSPORT IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY LOSS, INCLUDING BUT NOT LIMITED TO ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

How to get a defective part replaced:

- 1) Call the JumpSport Customer Service department at 1-888-567-5867 to obtain a Return Authorization number. All returns must be pre-authorized.
- 2) Send the part(s) to the designated Service Center, along with a copy of your original sales receipt and a brief written description of the problem, including how it occurred. You must pay freight and insurance to return the part to JumpSport. At JumpSport's sole discretion, we may ask you to send photographs in addition to or in lieu of returning the part.
- 3) After inspecting the returned part(s), JumpSport will make a final determination whether the part is covered by this warranty. We reserve the right to examine photographs or physical evidence concerning parts claimed to be defective prior to making a final determination concerning the claim. A repaired or replacement part will be returned to you. Please allow 3 to 4 weeks for delivery.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

JumpSport, Inc.

1680 Dell Ave.

Campbell, CA 95008

1-877-507-1399

<http://www.jumpsportfitness.com>