


JumpSport®



Trampoline Anchor Kit Installation Instructions

Retain address information for future use.

JumpSport, Inc.
2055 South 7th Street, Suite A
San Jose, CA 95112 U.S.A.

408-213-2551
www.jumpsport.com

P/N: INS-P-10639-01B

Copyright Notice

This material is protected by United States copyright laws and is proprietary to JumpSport, Inc. Disclosure, reproduction, translation, modification, or use of this document by anyone other than authorized employees, authorized users, or licensees of JumpSport without the prior written consent of JumpSport, Inc. is prohibited.

The information in this document is subject to change without notice. JumpSport, Inc. shall not be liable for any damages resulting from technical errors or omissions, which may be present in this document, or from use of this document.

Copyright © 2003-2014, by JumpSport, Inc. All rights reserved.

Printed: 2014

Instruction Manual P/N: INS-P-10639-01A

JumpSport Trampoline Anchor Kit P/N: ANJ-S-10625-01

Trademarks

JumpSport® is a trademark of JumpSport, Inc.

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

How to Contact Customer Support

Should you require customer service or technical support for your JumpSport Trampoline Anchor Kit, please contact JumpSport's Customer Service department at:

United States:

408-213-2551

6:00am – 5:00pm Monday through Friday, Pacific Time

Australia:

1800-822-117



Assembly and Installation Instructions

The JumpSport Trampoline Anchor Kit is designed to help secure most trampolines during windy conditions.

The following pages contain diagrams, pictures, and written instructions for installing your Trampoline Anchor Kit.

Familiarize yourself with the Assembly and Installation Instructions before beginning installation.

WARNING

- Anchors will protrude out of the ground. Do not use this kit without also having a trampoline enclosure. Falling off of the trampoline onto an anchor can result in serious injury or death.
- Mark anchors if landscaping or grass hides the top of the anchors.
- JumpSport cannot foresee every soil and weather condition where the anchors are used. JumpSport does not state, grant, or imply any guarantees as to performance of this anchor kit in any application whatsoever.


Note: To mow the lawn, simply detach strap from stake and move trampoline. When done, move trampoline back and reattach strap to stake.

Parts List

Your Trampoline Anchor Kit comes with 4 Anchor Straps and 4 Anchor Stakes.




Assembly and Installation Instructions



1) CAUTION: Before installing the Anchor Stakes, be sure that there are no underground utilities (such as electrical, gas, phone, water, and sprinkler) beneath where you are going to install the Anchor Stakes.

Anchor Stake should be installed near center of horizontal leg on trampoline and should be as close to horizontal leg piece as possible, allowing for the Anchor Strap to easily reach it. Push tip of Anchor Stake into ground. Then twist Anchor Stake into ground using the leverage of a pry-bar, large screwdriver, or similar item. Twist Anchor Stake into ground so that "eye" at end of Anchor Stake is approximately 1 inch above the ground. Open end of "eye" should be facing away from horizontal leg piece.

Note: Ground types vary. You may need to wet the ground thoroughly where you will be placing the Anchor Stake.



2) Position Anchor Strap at center of horizontal leg piece on trampoline. As shown, wrap the strap over top rail of trampoline, once around the base of the leg, so that the leg is held to the frame, through the anchor, and feed through buckle. Pull tight and trim if needed.

Note: If you have a DoubleBed trampoline, wrap long strap around lower rail only.

Repeat Steps at the 3 remaining horizontal legs. If your trampoline has 6 horizontal leg pieces instead of 4, install the Anchor Strap on 2 adjacent legs, skip a leg, and install on the next 2 adjacent legs.

Your Trampoline Anchor Kit is now installed!

To remove the anchor kit, follow the Installation Instructions in reverse order.

JumpSport®

90 Day Limited Warranty

What is covered by this warranty? This warranty covers any defects in materials or workmanship on all of the components of the JumpSport Trampoline Anchor Kit, and is extended exclusively to the original retail purchaser.

How long does this coverage last? Warranty coverage for each component begins from the original date of purchase and lasts for 90 days.

What will JumpSport do? If you return the defective part to JumpSport, as instructed below, JumpSport will either repair or replace such part, at JumpSport's discretion, and return it to you.

What is not covered by this warranty? This warranty does not cover expenses of on-site labor, shipping costs, travel, assembly or disassembly, or other charges associated with the repair or replacement of covered components. This warranty also does not cover any problem that is caused by abuse, misuse, commercial or public use, ordinary wear and tear, weathering, acts of God (such as wind and lightning), failure to follow directions, improper installation, improper maintenance, or any silk screened graphics. Rust is a natural occurrence with any outdoor steel product and is likewise not covered by this warranty, to the extent that it does not affect the structural integrity of the part.

JUMPSPORT IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY LOSS, INCLUDING BUT NOT LIMITED TO ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

How to get a defective part replaced:

- 1) Call the JumpSport Customer Service department at 408-213-2551 to obtain a Return Authorization number. All returns must be pre-authorized.
- 2) Send the part(s) to the designated Service Center, along with a copy of your original sales receipt and a brief written description of the problem, including how it occurred. You must pay freight and insurance to return the part to JumpSport. At JumpSport's sole discretion, we may ask you to send photographs in addition to or in lieu of returning the part.
- 3) After inspecting the returned part(s), JumpSport will make a final determination whether the part is covered by this warranty. We reserve the right to examine photographs or physical evidence concerning parts claimed to be defective prior to making a final determination concerning the claim. A repaired or replacement part will be returned to you. (Shipping charges may apply.) Please allow 3 to 4 weeks for delivery.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

JumpSport, Inc.
2055 South 7th Street, Suite A
San Jose, CA 95112

408-213-2551

<http://www.jumpsport.com>