


Arched Leg Non-Folding Trampolines LEG-A-20159-03 (2012-current)





Arched Leg Folding Trampolines LEG-A-20159-02



Note: If the leg is disassembled, the O ring will need to be pushed onto the threaded part of the screw once it is pushed through the washer and bushing.

Arched Leg Non-Folding Trampolines LEG-A-20159-01 (pre 2012)



WARNING: Periodically check all leg mounting bolts and retighten if necessary. All bolts should be tight prior to using the rebounder trampoline.



Note: Keep Allen wrench to remove or re-tighten legs, as needed.

With trampoline upside-down, fit leg sockets over stud on trampoline frame. Notch in leg socket lines up with pin on stud. All leg hardware fits inside of each leg socket as shown on the previous pages. For non-folding models securely tighten Allen bolts with supplied 6mm Allen wrench. If you have a folding model, securely tighten the screw by hand. A 6mm Allen can be used to provide additional assistance to secure the leg by inserting the short end into the hole of the screw.

The JumpSport Fitness Trampoline is now ready for use!