


JumpSport[®]



Frame Pad Installation Instructions

Retain address information for future use.

JumpSport, Inc.
2055 South 7th Street, Suite A
San Jose, CA 95112 U.S.A.

408-213-2551
www.jumpsport.com

P/N: INS-P-10486F

Copyright Notice

This material is protected by United States copyright laws and is proprietary to JumpSport, Inc. Disclosure, reproduction, translation, modification, or use of this document by anyone other than authorized employees, authorized users, or licensees of JumpSport without the prior written consent of JumpSport, Inc. is prohibited.

The information in this document is subject to change without notice. JumpSport, Inc. shall not be liable for any damages resulting from technical errors or omissions, which may be present in this document, or from use of this document.

Copyright © 2003-2009, by JumpSport, Inc. All rights reserved.

Printed: 2009

Instruction Manual P/N: INS-P-10486F

JumpSport 12ft Standard 6-leg Frame Pad P/N: PAD-S-11578A

JumpSport 12ft Standard Universal Frame Pad P/N: PAD-S-11378A

JumpSport 14ft Standard Universal Frame Pad P/N: PAD-S-11379A

JumpSport 14ft Deluxe Universal Frame Pad P/N: PAD-S-11380A

Trademarks

JumpSport® is a trademark of JumpSport, Inc.

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

How to Contact Customer Support

Should you require customer service or technical support for your JumpSport Frame Pad, please contact JumpSport's Customer Service department at:

408-213-2551

8:00am – 5:00pm Monday through Friday, Pacific Time



Assembly and Installation Instructions

Thank you for purchasing a JumpSport Frame Pad!

The following pages contain diagrams, pictures, and written instructions for installing your frame pad.

Familiarize yourself with the Assembly and Installation Instructions before beginning installation.



Trampoline use is not recommended without the frame pad installed (see Picture A, below). The frame pad is designed to reduce the possibility of injury by protecting the user from coming into contact with the frame and springs of the trampoline. It is very important that you properly and securely attach the frame pad to the frame, and that it is in the correct position prior to using the trampoline.




Frame Pad Placement - Showing Correct Placement over Frame Rails and Springs
(Section of frame pad removed for clarity. Be sure pad is completely installed before use.)


Parts List

Your JumpSport Frame Pad comes with a 8 frame pad sections and 16 Velcro pad connectors.

Assembly and Installation Instructions




- 1) Lay the 8 frame pad sections on the trampoline to create a full circle around the trampoline frame. Align pad so that small flaps on outside edge of pad skirt line up over each leg of trampoline.



- 2) Two pad connectors are used to connect adjacent pad sections together; one pad connector connects to the top of each pad section and the second pad connector connects to the bottom of each pad section.

Assembly and Installation Instructions




3) Between the poles on the top of the frame pad, you will find a button bungee. Lift the pad at one of these button bungee locations. The bungee on the bottom side of the pad will be used to secure the pad around the frame of the trampoline.



4) Secure button bungee around frame of trampoline, as shown.

>> Repeat at every location on bottom of pad where you see a bungee T-anchor until all 16 button bungees are securely fastened to the frame of the trampoline.

Assembly and Installation Instructions



5) Top of frame pad will have factory-installed bungees, as shown above. These bungees are used to secure the bottom of your JumpSport safety enclosure (if you have one installed). See the latest Safety Enclosure User's Manual (Models 120, 280, 380, 480, & 480XT) on our webpage for reference: www.jumpsport.com/assembly.htm

Your Frame Pad is now installed!

To remove the frame pad, follow the Installation Instructions in reverse order.

JumpSport®

Limited Warranty

What is covered by this warranty? This warranty covers any defects in materials or workmanship on all of the components of the JumpSport Frame Pad, and is extended exclusively to the original retail purchaser.

How long does this coverage last? Warranty coverage for each component begins from the original date of purchase and lasts as follows:

- Standard Frame Pad – 6 months
- Standard Universal Frame Pad – 6 months
- Deluxe Universal Frame Pad – 1 year

What will JumpSport do? If you return the defective part to JumpSport as instructed below, JumpSport will either repair or replace such part, at JumpSport's discretion, and return it to you.

What is not covered by this warranty? This warranty does not cover expenses of on-site labor, shipping costs, travel, assembly or disassembly, or other charges associated with the repair or replacement of covered components. This warranty also does not cover any problem that is caused by abuse, misuse, commercial or public use, ordinary wear and tear, weathering, acts of God (such as wind and lightning), failure to follow directions, improper installation, improper maintenance, or any silk screened graphics. Rust is a natural occurrence with any outdoor steel product and is likewise not covered by this warranty, to the extent that it does not affect the structural integrity of the part.

JUMPSPORT IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY LOSS, INCLUDING BUT NOT LIMITED TO ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

How to get a defective part replaced:

- 1) Call the JumpSport Customer Service department at 408-213-2551 to obtain a Return Authorization number. All returns must be pre-authorized.
- 2) Send the part(s) to the designated Service Center, along with a copy of your original sales receipt and a brief written description of the problem, including how it occurred. You must pay freight and insurance to return the part to JumpSport. At JumpSport's sole discretion, we may ask you to send photographs in addition to or in lieu of returning the part.
- 3) After inspecting the returned part(s), JumpSport will make a final determination whether the part is covered by this warranty. We reserve the right to examine photographs or physical evidence concerning parts claimed to be defective prior to making a final determination concerning the claim. A repaired or replacement part will be returned to you. (Shipping charges may apply.) Please allow 3 to 4 weeks for delivery.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

JumpSport, Inc.
2055 South 7th Street, Suite A
San Jose, CA 95112

408-213-2551

<http://www.jumpsport.com>